



## Storm Clean<sup>®</sup> Filtration Insert

### Water Quality and Compliance Sampling

- 1) Remove protective grate to access the CleanWay filtration insert.



- 2) Remove sample port plug from the support pan.



- 3) Insert the sampling container through sample port.



- 4) Replace the sample port plug into the support pan. Replace the grate after sampling is complete.

